

# TUNAI

## TUNAI WAND

BLUETOOTH TRANSMITTER

www.tunai-creative.com  
www.facebook.com/tunai.global/  
www.instagram.com/tunai\_creative\_eng/

### IMPORTANT NOTICE

- DO NOT expose the product under direct sunlight for long hours
- DO NOT disassemble the product, unauthorized disassembly will result warranty to expire
- USE ONLY power adapters with 5V output


### WARRANTY

TUNAI provides one year product warranty, please keep your purchase proof and package.

The warranty does not cover the following :

1. Consumable parts (example : exterior coating damage)
2. Appearance damage.
3. Damage caused by improper use with other products.
4. Damage caused by failure to comply with instructions.
5. Purchased from unauthorized seller.
6. Unauthorized disassembly of the product.
7. Damage caused by accident, abuse, improper use, fire, earthquake or other external causes.

### TUNAI WAND OVERVIEW



### INPUT PORTS

- Micro USB : Power supply and USB audio input
- AUX : 3.5mm audio input
- SPDIF : Optical audio input

### BUTTON

- Short press : Mode change / Wake up
- Long press 3 seconds : Force WAND to enter pairing mode
- Long press 5 seconds : Power down

### LED Indicator

#### LED Color

- White AUX
- Blue SPDIF
- Orange Micro USB

#### LED Status

##### Rapid Flash Pairing Mode

Slow Flash Available for previous paired device to connect

LED On Connected

LED Off LED goes off automatically after 5 minutes

LED Rapid Flash in WAND is pairing with both Bluetooth earphone using color cycle aptX low latency

### INSTALLATION

1. Connect WAND and USB power adapter with the included micro USB cable. LED will flash once powered.
2. Connect WAND and the audio source to the input port using the corresponding cable (micro USB and 3.5mm to RCA is included).

- TUNAI WAND User Manual -

- TUNAI WAND User Manual -

- TUNAI WAND User Manual -

### PAIRING

#### ENTER PAIRING MODE

1. WAND will enter pairing mode when powered for the first time.
2. LED will flash rapidly when entering pairing mode.
3. To force re-enter pairing mode, long press button for 3 seconds.

#### PAIRING WITH BLUETOOTH HEADPHONES

1. Force both WAND and Bluetooth headphone to enter pairing mode. WAND will enter pairing mode automatically when powered for the first time.
2. WAND will be connected with Bluetooth headphone automatically once both enters pairing mode.
3. LED indicator stop flashes once paired

#### PAIRING WITH 2nd BLUETOOTH HEADPHONES

1. Disconnect the first Bluetooth headphone with WAND. Force both WAND and second Bluetooth headphone to enter pairing mode. Wait until WAND finish pairing with second Bluetooth headphone.
2. Power on the first Bluetooth headphone, and wait for the headphone to reconnect with WAND automatically. When both Bluetooth headphone is pairing with aptX low latency, you will need to wait for 10-15 seconds until signal is synchronized. While synchronizing, LED will rapid flash in 3 color cycle. Once synchronization is completed, LED will stop flashing and constant on.

### AUDIO CODECS

WAND supports aptX for high-quality audio, aptX for low latency and standard SBC. To connect with aptX or aptX low latency, Bluetooth headphone will need to also support these audio CODECs. Otherwise, standard SBC will be used for the connection.

Connection priority :

AUX : aptX low latency > SBC

SPDIF : aptX low latency > aptX > SBC

Micro USB : aptX low latency > aptX > SBC

- TUNAI WAND User Manual -

- TUNAI WAND User Manual -